

MIKROSEN

LINEAR INDUCTIVE DISPLACEMENT SENSOR LD-L21-2305A

M178

## CALIBRATION PROCEDURE

## STEPS TO BE FOLLOWED:

- a) The Zero & Span Potentiometers are used for the Calibration described below.
- b) The Output Current of the Linear Displacement Sensor is measured at the Blue wire in Resistor of 1Watt across Blue and Black wire in series with a DMM the Output cable supplied, with reference to Black wire of the cable. Insert a 200 Ohms
- c) Insert a 1mm slip gauge between the Rollers.

Set Output Current to 4mA using the trimming potentiometer marked as Zero.

The Span LED (Green) will become ON at this position

1.0 mm Slip Gauge

Current 4mA ± 0.02 mA

d) Insert a 5mm slip gauge between the Rollers.

Set Output Current to 20mA using trimming potentiometer marked as Span.

The Span LED (Green) will become OFF at this position.

5.0 mm Slip Gauge

Current 20mA ± 0.02mA

- e) Repeat steps 'c' and 'd' until the above values are obtained
- f) To check the adjustment use a 3mm slip gauge. Insert a 3mm slip gauge between the Rollers. In this case the Output Current of the Measuring System should equal

12mA. The Span LED (Green) will be ON at this position.

3 mm Slip Gauge Current 12mA ± 0.15mA

Revised on Sign

PREPARED: APPROVED ISSUED ON .

SHEET NO.: 2/2